Installation Guide



Warning, before installation you must ensure that the wall you are fixing to is free from any hidden electrical wire or pipe work. If in doubt consult with a qualified trades person. Installation of the shelf must be carried out by a competent person. For best results we strongly recommend that our shelves are fixed to a solid built wall (Brick or concrete). Please note: This is a guide only, different walls will require different fixing methods which may not be included.

Parts included;




You will need:



Installation

- 1) Place one shelf support in the desired location and mark the hole positions on the wall.
- Draw a level line from the first hole positions, measure and mark the hole positions for the second shelf support.
- 3) Drill the holes using a 10mm masonry drill bit ensuring the holes are deeper than the length of the screws.
- Knock the wall plugs into the holes finishing just under the surface of the wall.
- Screw the shelf supports to the wall ensuring a strong hold. PLEASE NOTE: If fixing onto a dot dabbed plaster board wall, you will need to cut the plasterboard to the size of the bracket and pack out with timber finishing flush with the plasterboard.
- 6) The shelf can now be fitted to the supports and adjusted in the height and inclination as shown below:
- Optional Once adjusted level, secure the shelf to the wall by running a thin bead of clear silicon down the back edge of the shelf.



Three Way Adjustment:

*Vertical - Using the 10mm hex socket. Loosen the coach bolts and adjust up and down as required.

*Horizontal - Using the adjustable spanner. Loosen the shelf support arm. And adjust side to side as required.

*Tilt - Using the screwdriver. Slowly tighten the two grub screws on the face of the bracket evenly. This will open the bracket and increase the angle of the shelf against the wall. Take care not to damage the head of the grub screws.

